

**Metal mesh protection**

**CHAINEXTRA Glove with removable plastic strap**  
**REF. 254200XR0302**



**OVERVIEW**

**Division :** Body protection

**Family:** Protective gloves

**Range:** Cut and puncture protection

**Brand formerly known as:** CHAINEX

**Business countries:** EMEA

**Activity domains:** Food industries (mainly meat)

**Product use:** Works when using knives or cutting and/or punching tools (slaughterhouses, cutting workshops)

**BENEFITS**

**Feature**

**COMFORT**

Its ultra-flexible plastic strap adapts itself to all shapes and sizes while ensuring a comfortable and ergonomic fit. The plastic straps are easily removable without any tools: they can be purchased and replaced by the user.

**TRACING**

Each CHAINEXTRA glove is identified by a unique number (1 number = 1 glove): to follow up the attribution of the glove, lifetime, repairs...

**RESISTANCE**

The exceptional quality of the CHAINEX chainmail is an additional guarantee of durability.

**SAFETY**

The plastic strap is notched, the tightening buckle does not slip on the strap, providing additional security to the wearer.

**HYGIENE**

The strap contains an antibacterial agent to prevent contamination.  
Stainless steel composition of the glove, fully compatible with food contact.

**BENEFITS**

Plastic strap with snap button closure and adjustable buckle.  
Version: Reversible

**Metal mesh protection****TECHNICAL DESCRIPTION****Description :**

Protected area: hand  
Plastic strap closure with press stud and adjustable buckle  
Chainmail in stainless steel AISI 316L diam 0.5mm  
External diameter of the ring 4mm  
Version: Reversible

Sizes: 0 – 1 – 2 – 3 – 4 – 5 – 6

Size	Color code	Total Length +/- 8 mm	Length of the cuff +/- 8 mm	Weight (gr)
XXS (0)	Brown	208	0	149
XS (1)	Green	220	0	159
S (2)	White	232	0	176
M (3)	Red	245	0	195
L (4)	Blue	257	0	213
XL (5)	Orange	270	0	229
XXL (6)	Olive	285	0	246

**ADDITIONAL INFORMATION****Care Instructions:**

Cleaning: washing machine or scrubbing at least once a day in hot soapy water (50°C) or in a mixture of hot water (50°C) and detergent. Rinsing in hot water at a minimum temperature of 82°C. Disinfection only with approved products. They can also be cleaned in a washing machine. Do not clean chainmail protective gloves by knocking them against a hard surface.

**Storage information:** After cleaning, store the gloves in a cool, dry and well ventilated place.

Any glove showing signs of wear or missing chainmail must be replaced immediately by a glove in good condition. Only the manufacturer is authorized to repair defective gloves or to declare a glove beyond repair.

**Tagging:**

Every glove is packaged in a bag or a case on which is pasted a tag indicating the model, together with a multilingual instruction for use in 21 languages: DE, DK, GB, SP, EST, FIN, FR, GR, HON, IT, ISL, LET, LITU, NOR, NL, POL, POR, RUS, SK, SUE, TCH.

**CERTIFICATION AND CONFORMITY****EC category PPE\*: Class 2****Standard:**

EN 1082-1 Regulation 2016/425

**European directive:** 89/686/EEC

**Quality Assurance:**

ISO 9001 / 2015

**EC certificate number:**

NV 24060-CHAINEXTRA

**Test Laboratory:**

DGUV TEST

FACHAUSSCHUSS PERSÖNLICHE SCHUTZAUSRÜSTUNGEN  
PRÜF- UND ZERTIFIZIERUNGSSTELLE

\*PPE : Personal Protective Equipment

Protective gloves

**Honeywell**

**Metal mesh protection**

**DECLARATION OF CONFORMITY**

The manufacturer or its legal representative supplier in the European Community:

**Honeywell Safety Products Europe**

**Declares that the Personal Protective Equipment described here after conforms to the provisions of the European Council Directive 89/686/CEE:**

**Designation:** CHAINEXTRA

**Reference:** 254200XR0302

**Standard:** EN 1082-1 Regulation, 2016/425

**This PPE is the object of the below EC examination certificate nr:**

NV 24060-CHAINEXTRA

**Delivered by:**

DGUV TEST  
FACHAUSSCHUSS PERSÖNLICHE SCHUTZAUSRÜSTUNGEN  
PRÜF- UND ZERTIFIZIERUNGSSTELLE  
PRÜFLABORATORIUM II - Lortzingstrasse 2  
55127 MAINZ

Done in Roissy, 07.03.2019

By

Division : Body Protection

A handwritten signature in black ink, appearing to be 'J. S.', is written vertically on the left side of the page.